

## KEY TO THE FRONT SUSPENSION

No.	Description	No.	Description
1.	Upper arm pivot pin.	64.	Swivel hub (left- and right-hand).
2.	Pivot pin nut.	65.	Steering-arm (left- and right-hand).
3.	Plain washer.	66.	Bolt.
4.	Lower arm pivot pin.	67.	Dowel.
5.	Pivot pin nut.	68.	Lock washer.
6.	Spring washer.	69.	Lubricator.
7.	Plain washer.	70.	Drive shaft assembly (left- and right-hand).
8.	Lower arm bush.	71.	Rubber boot.
9.	Locating bush.	72.	Flange.
10.	Retaining plate (left- and right-hand).	73.	Seal.
11.	Retaining plate bolt.	74.	Inner oil seal.
12.	Nut.	75.	Spacer.
13.	Spring washer.	76.	Inner bearing.
14.	Bolt.	77.	Distance piece.
15.	Nut.	78.	Outer bearing.
16.	Spring washer.	79.	Outer oil seal.
17.	Tie-rod	80.	Driving flange.
18.	Tie-rod bolt.	81.	Wheel stud.
19.	Nut.	82.	Wheel nut.
20.	Spring washer.	83.	Drive shaft collar.
21.	Pad.	84.	Drive shaft nut.
22.	Cup washer.	85.	Lower support arm (left- and right-hand).
23.	Tie-rod nut.	86.	Lower ball pin.
24.	Bump rubber.	87.	Nut.
25.	Nut.	88.	Spring washer.
26.	Spring washer.	89.	Ball seat.
27.	Rebound buffer.	90.	Spring.
28.	Lock washer.	91.	Retainer.
29.	Nut.	92.	Shim.
30.	Spring washer.	93.	Lock washer.
31.	'U' bolt.	94.	Dust cover.
32.	Nut.		
33.	Displacer unit.		
34.	Valve assembly.		
35.	Valve core.		
36.	Valve cap.		
37.	Interconnecting pipe (left- and right-hand).		
38.	Clip.		
39.	Distance piece.		
40.	Screw.		
41.	Spring washer.		
42.	Roller joint foot.		
43.	Roller joint seat.		
44.	Locating bush.		
45.	Retaining pad.		
46.	Retaining bush.		
47.	Circlip.		
48.	Roller joint seal.		
49.	Washer.		
50.	Upper arm support assembly (left- and right-hand).		
51.	Pivot shaft bearing.		
52.	Pivot tube.		
53.	Distance collar.		
54.	Spacer.		
55.	Locking pin.		
56.	Upper ball pin.		
57.	Nut with bumper cup.		
58.	Lock washer.		
59.	Ball seat.		
60.	Ball pin retaining shim.		
61.	Ball pin shim.		
62.	Lock washer.		
63.	Dust cover.		