

## KEY TO THE REAR SUSPENSION COMPONENTS

<i>No.</i>	<i>Description</i>	<i>No.</i>	<i>Description</i>	<i>No.</i>	<i>Description</i>
1.	Displacer unit.	20.	Bracket.	38.	Dust seal.
2.	Piston sleeve.	21.	Screw.	39.	Outer spacer.
3.	Displacer strut.	22.	Nut.	40.	Inner spacer.
4.	Roller joint foot.	23.	Bracket (left- and right-hand).	41.	Pivot shaft.
5.	Roller joint seat.	24.	Bolt.	42.	Retaining plate (left- and right-hand).
6.	Locating bush.	25.	Spring washer.	43.	Nut.
7.	Retaining pad.	26.	Plain washer.	44.	Spring washer.
8.	Retainer.	27.	Nut.	45.	Stud.
9.	Circlip.	28.	Spring washer.	46.	Brake-drum hub assembly.
10.	Seal.	29.	Screw.	47.	Wheel stud.
11.	Washer.	30.	Spring washer.	48.	Wheel nut.
12.	Bump rubber.	31.	Plain washer.	49.	Oil seal.
13.	Screw.	32.	Radius arm (left- and right-hand).	50.	Inner bearing.
14.	Spring washer.	33.	Stub shaft (left- and right-hand).	51.	Spacer.
15.	Rebound buffer.	34.	Circlip.	52.	Outer bearing.
16.	Anti-roll bar.	35.	Locking pin.	53.	Washer.
17.	Auxiliary spring (left- and right-hand).	36.	Oil seal.	54.	Nut (left- and right-hand).
18.	Bearing.	37.	Pivot shaft bearing.	55.	Grease-retaining cap.
19.	Nut.				