

# SECTION H

## THE REAR SUSPENSION

	<i>Section</i>
Hubs .. .. .	H.5
Hydrolastic suspension .. .. .	H.7
Depressurizing, evacuating, pressurizing .. .. .	H.8
Displacer units .. .. .	H.9
Radius arms .. .. .	H.11
Schrader valve extension housing .. .. .	H.15
Sub-frame .. .. .	H.12
Suspension pressures and wing heights .. .. .	H.10
Radius arms .. .. .	H.2
Radius arms (Moke) .. .. .	H.14
Spring units .. .. .	H.3
Struts .. .. .	H.6
Sub-frame .. .. .	H.1
Sub-frame (Moke) .. .. .	H.13
Sub-frame mountings .. .. .	H.4
Tools .. .. .	End of Section