

SECTION K

THE FRONT SUSPENSION

	<i>Section</i>
Castor and camber angles and swivel hub inclination	K.1
Hydrolastic suspension	
Description	H.7
Depressurizing, evacuating, pressurizing	H.8
Displacer units	K.8
Upper suspension arms	K.9
Rubber suspension	
Lower arms	K.6
Spring units	K.2
Struts	K.7
Upper arm	K.5
Swivel hub ball joints	K.4
Swivel hub outer oil seal	K.10
Swivel hubs	K.3
Tools End of Section