

## SECTION K

### THE FRONT SUSPENSION

	<i>Section</i>
Castor and camber angles and swivel hub inclination .. .. .	K.1
Hydrolastic suspension	
Description .. .. .	H.7
Depressurizing, evacuating, pressurizing .. .. .	H.8
Displacer units .. .. .	K.8
Upper suspension arms .. .. .	K.9
Rubber suspension	
Lower arms .. .. .	K.6
Spring units .. .. .	K.2
Struts .. .. .	K.7
Upper arm .. .. .	K.5
Swivel hub ball joints .. .. .	K.4
Swivel hub outer oil seal .. .. .	K.10
Swivel hubs .. .. .	K.3
Tools .. .. .	.. End of Section