



18G 582. Front Suspension and Idler Gear Needle Bearing Replacer



A1441

18G 582

18G 582 A. Front Suspension and Idler Gear Needle Bearing Replacer Adaptor




A1439

18G 582 A

18G 587. Swivel Hub Ball Pin Nut Spanner

This socket must be used with torque wrench 18G 372 in order that the correct torque figure may be applied to the swivel hub ball nut on reassembly.




A1426

18G 587

18G 574 B. Suspension Rubber Spring Compressor

This tool will enable the front suspension rubber cone spring to be compressed with ease during dismantling and reassembly of the suspension arms without damaging the thread of the nut welded into the spring unit for purposes of spring compression.

WARNING.—This tool must not be used if the spindle thread is badly worn or damaged. Replacement spindles (Part No. 18G 574 A) are available and should be obtained if the threads on the existing spindle are at all suspect.



18G 574 B

1713A